



**EXECUTOR NOTE**  
 THE FINISH JAMB FRAME SHALL BE INSTALLED FIRST. ALL WINDERS SHALL BE SECURELY BLOCKED AND ANCHORED TO THE CONCRETE THROUGH THE HOLES OR AS CLOSE AS POSSIBLE TO THE HINGES.

