



**EXECUTOR NOTE:**  
 THE FINISH JAMB FRAME SHALL BE INSTALLED FIRST. ALL WINDERS SHALL BE SECURELY BLOCKED AND ANCHORED TO THE CONCRETE THROUGH THE HOLES OF AS CLOSE AS POSSIBLE TO THE HINGE.

